



Verkho Series

Verkho 1-3P / Verkho 2 / Verkho 2 Plus / Verkho 3 / Verkho 3 Plus

Socket : LGA 1150 / 1151 / 1155 / 1156 / 1366 / 775









Socket : AM4 / AM3+ / AM3 / AM2+ / AM2 / FM2 / FM1

User's Manual
Manual del usuario
Bedienungsanleitung
Manuel d'utilisation

Manuale dell'utente
Podręcznik użytkownika
Руководство пользователя
Manual de utilizador

使用説明書/使用说明书
ユーザーズマニュアル
нұсқаулары
Talimatlar

Intel
AMD





Verkho Series

Verkho 1-3P / Verkho 2 / Verkho 2 Plus / Verkho 2 Dual / Verkho 3 / Verkho 3 Plus





Socket : LGA 1150 / 1151 / 1155 / 1156 / 1366 / 775

Socket : AM4 / AM3+ / AM3 / AM2+ / AM2 / FM2 / FM1

User's Manual
Manual del usuario
Bedienungsanleitung
Manuel d'utilisation

Manuale dell'utente
Podręcznik użytkownika
Руководство пользователя
Manual de utilizador

使用説明書/使用说明书
ユーザーズマニュアル
нұсқаулары
Talimatlar



aerocool.com.tw